



**MIGSONIC252S power source
SS20 wire feeder**

OWNER'S MANUAL



MIG (GMAW)
Flux cored (FCAW)

Arc Welding Power Source and wire feeder

Manufactured at



Certified Facility

Power Source Serial Number: _____

Wire feeder Serial Number: _____

Where Purchase: _____

Date of purchased: _____

Table of Contents

| | | |
|-------------------|--|-----------|
| SECTION 1 | SAFETY PRECAUTIONS..... | 1 |
| SECTION 1 | CONSIGNES DE SÉCURITÉ..... | 1 |
| 1-1. | Symbol Usage Symboles utilisés..... | 1 |
| 1-2. | Arc welding Hazards Dangers relatifs au soudage à l'arc..... | 1 |
| 1-3. | Safety Standards Normes de sécurité..... | 6 |
| 1-4. | EMF Information EMF Information..... | 6 |
| SECTION 2 | PACKING LIST..... | 7 |
| SECTION 3 | INSTALLATIONS..... | 8 |
| 3-1. | Welding power source and wire feeder specifications..... | 8 |
| 3-2. | MIG torch specifications..... | 10 |
| 3-3. | MIG welding connection diagram..... | 11 |
| 3-4. | MIG/MAG Process/Polarity Table..... | 12 |
| 3-5. | General Installation procedure for MIG/MAG welding..... | 12 |
| 3-6. | How to Install the wire spool..... | 12 |
| 3-7. | How to Adjust wire feed pressure..... | 13 |
| 3-8. | How to Install spool gun(optional)..... | 14 |
| 3-9. | Electric service guide..... | 14 |
| 3-10. | Extension Welding Cable Selection Chart..... | 16 |
| 3-11. | 9-pin spool gun connection receptacle..... | 16 |
| 3-12. | 7-pin link cord receptacle..... | 17 |
| SECTION 4 | OPERATION..... | 18 |
| 4-1. | Power source panel layout and description..... | 18 |
| 4-2. | SS-2- wire feeder panel layout and description..... | 20 |
| 4-3. | Operation..... | 21 |
| 4-4. | Voltage/Wire speed selection chart..... | 22 |
| SECTION 5 | TROUBLE SHOOTING..... | 23 |
| 5-1. | General trouble shooting..... | 23 |
| 5-2. | GMAW/FCAW welding trouble shooting..... | 24 |
| SECTION 6 | MAINTENANCE..... | 27 |
| 6-1. | Maintenance..... | 27 |
| 6-2. | Safety precaution..... | 28 |
| SECTION 7 | PARTS LIST..... | 29 |
| 7-1. | MigSonic252S Power Source..... | 29 |
| 7-2. | SS-20 Wire feeder..... | 33 |
| 7-3. | Wire driving system..... | 37 |
| 7-4. | Spool holder module..... | 39 |
| 7-4. | MIG torch..... | 39 |
| SECTION 8 | ELECTRIC DIAGRAM..... | 44 |
| SECTION 9 | WARRANTY POLICY..... | 46 |
| SECTION 10 | AUTHORIZED SERVICE CENTER..... | 47 |

SECTION 1 SAFETY PRECAUTIONS

SECTION 1 CONSIGNES DE SÉCURITÉ

1-1. Symbol Usage Symboles utilisés



Means Warning! Watch Out! There are possible hazards with this procedure! The possible hazards are shown in the adjoining symbols.

Symbole graphique d'avertissement ! Attention ! Cette procédure comporte des risques possibles ! Les dangers éventuels sont représentés par les symboles graphiques joints.

▲ **Marks a special safety message.**
Indique un message de sécurité particulier

☞ **Means "Note"; not safety related.**
Signifie NOTE ; n'est pas relatif à la sécurité.



This group of symbols means Warning! Watch Out possible ELECTRIC SHOCK, MOVING PARTS, and HOT PARTS hazards. Consult symbols and related instructions below for necessary actions to avoid the hazards

Ce groupe de symboles signifie Avertissement! Attention! Risques d'ÉLECTROCUTION, ORGANES MOBILES et PARTIES CHAUDES. Consulter les symboles et les instructions afférents ci-dessous concernant les mesures à prendre pour supprimer les dangers.

1-2. Arc welding Hazards Dangers relatifs au soudage à l'arc

- ★ **The symbols shown below are used throughout this manual to call attention to and identify possible hazards. When you see the symbol, watch out, and follow the related instructions to avoid the hazard.**
- ★ **Only qualified persons should service, test, maintain, and re- pair this unit.**
- ★ **During servicing, keep everybody, especially children, away**
- ★ **Les symboles représentés ci-dessous sont utilisés dans ce manuel pour attirer l'attention et identifier les dangers possibles. En présence de l'un de ces symboles, prendre garde et suivre les instructions afférentes pour éviter tout risque. Les instructions en matière de sécurité indiquées ci-dessous ne constituent qu'un sommaire des instructions de sécurité plus complètes fournies dans les normes de sécurité énumérées dans la Section 2-5. Lire et observer toutes les normes de sécurité.**
- ★ **Seul un personnel qualifié est autorisé à installer, faire fonctionner, entretenir et réparer cet appareil.**
- ★ **Pendant le fonctionnement, maintenir à distance toutes les personnes, notamment les enfants de l'appareil.**



ELECTRIC SHOCK can kill.
UNE DÉCHARGE ÉLECTRIQUE entraîner la mort.

- Do not touch live electrical parts.
- Wear dry, hole-free insulating gloves and body protection.
- Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.

- Do not use AC output in damp areas, if movement is confined, or if there is a danger of falling.
- Use AC output ONLY if required for the welding process.
- If AC output is required, use remote output control if present on unit.
- Additional safety precautions are required when any of the following electrically hazardous conditions are present: in damp locations or while wearing wet clothing; on metal structures such as floors, gratings, or scaffolds; when in cramped positions such as sitting, kneeling, or lying; or when there is a high risk of unavoidable or accidental contact with the workpiece or ground. For these conditions, use the following equipment in order presented: 1) a semiautomatic DC constant voltage (wire) welder, 2) a DC manual (stick) welder, or 3) an AC welder with reduced open-circuit voltage. In most situations, use of a DC, constant voltage wire welder is recommended. And, do not work alone!
- Disconnect input power or stop engine before installing or servicing this equipment. Lockout/tagout input power according to OSHA 29 CFR 1910.147 (see Safety Standards).
- Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.
- Always verify the supply ground – check and be sure that input power cord ground wire is properly connected to ground terminal in disconnect box or that cord plug is connected to a properly grounded receptacle outlet.
- When making input connections, attach proper grounding conductor first – double-check connections.
- Frequently inspect input power cord for damage or bare wiring – replace cord immediately if damaged – bare wiring can kill.
- Turn off all equipment when not in use.
- Do not use worn, damaged, undersized, or

- poorly spliced cables.
- Do not drape cables over your body.
- If earth grounding of the workpiece is required, ground it directly with a separate cable.
- Do not touch electrode if you are in contact with the work, ground, or another electrode from a different machine.
- Do not touch electrode holders connected to two welding machines at the same time since double open-circuit voltage will be present.
- Use only well-maintained equipment. Repair or replace damaged parts at once. Maintain unit according to manual.
- Wear a safety harness if working above floor level.
- Keep all panels and covers securely in place.
- Clamp work cable with good metal-to-metal contact to workpiece or worktable as near the weld as practical.
- Insulate work clamp when not connected to workpiece to prevent contact with any metal object.
- Do not connect more than one electrode or work cable to any single weld output terminal.

SIGNIFICANT DC VOLTAGE exists after removal of input power on inverters.

Il reste une TENSION DC NON NÉGLIGEABLE dans les sources de soudage onduleur quand on a coupé l'alimentation.

- Turn Off inverter, disconnect input power, and discharge input capacitors according to instructions in Maintenance Section before touching any parts.
- Ne pas toucher aux pièces électriques sous tension.
- Porter des gants isolants et des vêtements de protection secs et sans trous.
- S'isoler de la pièce à couper et du sol en utilisant des housses ou des tapis assez grands afin d'éviter tout contact physique avec la pièce à couper ou le sol.
- Ne pas se servir de source électrique à courant électrique dans les zones humides, dans les endroits confinés ou là où on risque de tomber.
- Se servir d'une source électrique à courant électrique UNIQUEMENT si le procédé de soudage le demande.
- Si l'utilisation d'une source électrique à courant électrique s'avère nécessaire, se servir de la fonction de télécommande si l'appareil en est équipé.
- D'autres consignes de sécurité sont nécessaires dans les conditions suivantes : risques électriques dans un environnement humide ou si l'on porte des vêtements mouillés ; sur des structures métalliques telles que sols, grilles ou échafaudages ; en position coincée comme assise, à genoux ou couchée ; ou s'il y a un risque élevé de contact inévitable ou accidentel avec la pièce à souder ou le sol. Dans ces conditions, utiliser les équipements suivants, dans l'ordre indiqué : 1) un poste à souder DC à tension constante (à fil), 2) un poste à souder DC manuel (électrode) ou 3) un poste à souder AC à tension à vide réduite. Dans la plupart des

situations, l'utilisation d'un poste à souder DC à fil à tension constante est recommandée. En outre, ne pas travailler seul !

- Couper l'alimentation ou arrêter le moteur avant de procéder à l'installation, à la réparation ou à l'entretien de l'appareil. Déverrouiller l'alimentation selon la norme OSHA 29 CFR 1910.147 (voir normes de sécurité).
- Installer le poste correctement et le mettre à la terre convenablement selon les consignes du manuel de l'opérateur et les normes nationales, provinciales et locales.
- Toujours vérifier la terre du cordon d'alimentation. Vérifier et s'assurer que le fil de terre du cordon d'alimentation est bien raccordé à la borne de terre du sectionneur ou que la fiche du cordon est raccordée à une prise correctement mise à la terre.
- En effectuant les raccordements d'entrée, fixer d'abord le conducteur de mise à la terre approprié et contre-vérifier les connexions.
- Vérifier fréquemment le cordon d'alimentation afin de s'assurer qu'il n'est pas altéré ou à nu, le remplacer immédiatement s'il l'est. Un fil à nu peut entraîner la mort.
- L'équipement doit être hors tension lorsqu'il n'est pas utilisé.
- Ne pas utiliser des câbles usés, endommagés, de grosseur insuffisante ou mal épissés.
- Ne pas enrouler les câbles autour du corps.
- Si la pièce soudée doit être mise à la terre, le faire directement avec un câble distinct.
- Ne pas toucher l'électrode quand on est en contact avec la pièce, la terre ou une électrode provenant d'une autre machine.
- Ne pas toucher des porte électrodes connectés à deux machines en même temps à cause de la présence d'une tension à vide doublée.
- N'utiliser qu'un matériel en bon état. Réparer ou remplacer sur-le-champ les pièces endommagées. Entretien l'appareil conformément à ce manuel.
- Porter un harnais de sécurité si l'on doit travailler au-dessus du sol.
- S'assurer que tous les panneaux et couvercles sont correctement en place.
- Fixer le câble de retour de façon à obtenir un bon contact métal-métal avec la pièce à souder ou la table de travail, le plus près possible de la soudure.
- Isoler la pince de masse quand pas mis à la pièce pour éviter le contact avec tout objet métallique.
- Ne pas raccorder plus d'une électrode ou plus d'un câble de masse à une même borne de sortie de soudage.
- Arrêter les convertisseurs, débrancher le courant électrique et décharger les condensateurs d'alimentation selon les instructions indiquées dans la partie Entretien avant de toucher les pièces.



STATIC (ESD) can damage PC boards.
LES CHARGES ÉLECTROSTATIQUES peuvent endommager les circuits imprimés.

- Put on grounded wrist strap BEFORE handling boards or parts.
- Use proper static-proof bags and boxes to store, move, or ship PC boards.
- Établir la connexion avec la arrette de terre avant de manipuler des cartes ou des pièces.
- Utiliser des pochettes et des boîtes antistatiques pour stocker, déplacer ou expédier des cartes PC.



FIRE OR EXPLOSION hazard.

Risque D'INCENDIE OU D'EXPLOSION.

- Do not place unit on, over, or near combustible surfaces.
- Do not service unit near flammables
- Do not overload building wiring – be sure power supply system is properly sized, rated, and protected to handle this unit.
- Ne pas placer l'appareil sur, au-dessus ou à proximité de surfaces inflammables.
- Ne pas installer l'appareil à proximité de produits inflammables.
- Ne pas surcharger l'installation électrique – s'assurer que l'alimentation est correctement dimensionnée et protégée avant de mettre l'appareil en service.



FLYING METAL can injure eyes.

DES PARTICULES VOLANTES peuvent blesser les yeux.

- Wear safety glasses with side shields or face shield during servicing.
- Be careful not to short metal tools, parts, or wires together during testing and servicing.
- Le soudage, l'écaillage, le passage de la pièce à la brosse en fil de fer, et le meulage génèrent des étincelles et des particules métalliques volantes. Pendant la période de refroidissement des soudures, elles risquent de projeter du laitier.
- Porter des lunettes de sécurité avec écrans latéraux ou un écran facial.



HOT PARTS can cause severe burns.

DES PIÈCES CHAUDES peuvent provoquer des brûlures graves.

- Do not touch hot parts bare handed.
- Allow cooling period before working on welding gun or torch
- Ne pas toucher des parties chaudes à mains nues.
- Prévoir une période de refroidissement avant d'utiliser le pistolet ou la torche.



MAGNETIC FIELDS can affect pacemakers.

LES CHAMPS MAGNÉTIQUES peuvent affecter les stimulateurs cardiaques.

- Pacemaker wearers keep away.
- Wearers should consult their doctor before going near arc welding, gouging, or spot welding operations.
- Porteurs de stimulateur cardiaque, rester à distance.
- Les porteurs d'un stimulateur cardiaque doivent d'abord consulter leur médecin avant de s'approcher des opérations de soudage à l'arc, de gougeage ou de soudage par points.



CYLINDERS can explode if damaged.

LES BOUTEILLES peuvent exploser si elles sont endommagées.

Shielding gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, physical damage, slag, open flames, sparks, and arcs.
- Install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling or tipping.
- Keep cylinders away from any welding or other electrical circuits.
- Never drape a welding torch over a gas cylinder.
- Never allow a welding electrode to touch any cylinder.
- Never weld on a pressurized cylinder – explosion will result.
- Use only correct shielding gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
- Turn face away from valve outlet when opening cylinder valve.
- Keep protective cap in place over valve except when cylinder is in use or connected for use.
- Use the right equipment, correct procedures, and sufficient number of persons to lift and move cylinders.
- Read and follow instructions on compressed gas cylinders, associated equipment, and Compressed Gas Association (CGA) publication P-1 listed in Safety Standards.

Des bouteilles de gaz protecteur contiennent du gaz sous haute pression. Si une bouteille est endommagée, elle peut exploser. Du fait que les bouteilles de gaz font normalement partie du procédé de soudage, les manipuler avec précaution.

- Protéger les bouteilles de gaz comprimé d'une chaleur excessive, des chocs mécaniques, des dommages physiques, du laitier, des flammes ouvertes, des étincelles et des arcs.

- Placer les bouteilles debout en les fixant dans un support stationnaire ou dans un porte-bouteilles pour les empêcher de tomber ou de se renverser.
- Tenir les bouteilles éloignées des circuits de soudage ou autres circuits électriques.
- Ne jamais placer une torche de soudage sur une bouteille à gaz.
- Une électrode de soudage ne doit jamais entrer en contact avec une bouteille.
- Ne jamais souder une bouteille pressurisée – risque d'explosion.
- Utiliser seulement des bouteilles de gaz protecteur, régulateurs, tuyaux et raccords convenables pour cette application spécifique ; les maintenir ainsi que les éléments associés en bon état.
- Détourner votre visage du détendeur-régulateur lorsque vous ouvrez la soupape de la bouteille.
- Le couvercle du détendeur doit toujours être en place, sauf lorsque la bouteille est utilisée ou qu'elle est reliée pour usage ultérieur.
- Utiliser les équipements corrects, les bonnes procédures et suffisamment de personnes pour soulever et déplacer les bouteilles.
- Lire et suivre les instructions sur les bouteilles de gaz comprimé, l'équipement connexe et le dépliant P-1 de la CGA (Compressed Gas Association) mentionné dans les principales normes de sécurité.



FALLING UNIT can cause injury.
LA CHUTE DE L'APPAREIL peut blesser.

- Use lifting eye to lift unit only, NOT running gear, gas cylinders, or any other accessories.
- Use equipment of adequate capacity to lift and support unit.
- If using lift forks to move unit, be sure forks are long enough to extend beyond opposite side of unit
- Utiliser l'anneau de levage uniquement pour soulever l'appareil, NON PAS les chariots, les bouteilles de gaz ou tout autre accessoire.
- Utiliser un équipement de levage de capacité suffisante pour lever l'appareil.
- En utilisant des fourches de levage pour déplacer l'unité, s'assurer que les fourches sont suffisamment longues pour dépasser du côté opposé de l'appareil.



MOVING PARTS can cause injury.
DES ORGANES MOBILES peuvent provoquer des blessures.

- Keep away from moving parts such as fans.
- Keep all doors, panels, covers, and guards closed and securely in place.
- Have only qualified persons remove doors, panels, covers, or guards for maintenance as necessary.
- Reinstall doors, panels, covers, or guards when maintenance is finished and before reconnecting input power.
- S'abstenir de toucher des organes mobiles tels

que des ventilateurs.

- Maintenir fermés et verrouillés les portes, panneaux, recouvrements et dispositifs de protection.
- Seules des personnes qualifiées sont autorisées à enlever les portes, panneaux, recouvrements ou dispositifs de protection pour l'entretien.
- Remettre les portes, panneaux, recouvrements ou dispositifs de protection quand l'entretien est terminé et avant de rebrancher l'alimentation électrique.




MOVING PARTS can cause injury.
DES ORGANES MOBILES peuvent provoquer des blessures.

- Keep away from moving parts
- Keep away from pinch points such as drive rolls
- Ne pas s'approcher des organes mobiles.
- Ne pas s'approcher des points de coincement tels que des rouleaux de commande.



OVERUSE can cause OVERHEATING.
L'EMPLOI EXCESSIF peut SURCHAUFFER L'ÉQUIPEMENT.

- Allow cooling period; follow rated duty cycle.
- Reduce current or reduce duty cycle before starting to weld again.
- Do not block or filter airflow to unit
- Prévoir une période de refroidissement ; respecter le cycle opératoire nominal.
- Réduire le courant ou le facteur de marche avant de poursuivre le soudage.
- Ne pas obstruer les passages d'air du poste.



H.F. RADIATION can cause interference.
LE SOUDAGE À L'ARC risque de provoquer des interférences.

- High-frequency (H.F.) can interfere with radio navigation, safety services, computers, and communications equipment.
- Have only qualified persons familiar with electronic equipment perform this installation.
- The user is responsible for having a qualified electrician promptly correct any interference problem resulting from the installation.
- If notified by the FCC about interference, stop using the equipment at once.
- Have the installation regularly checked and maintained.
- Keep high-frequency source doors and panels tightly shut, keep spark gaps at correct setting, and use grounding and shielding to minimize

the possibility of interference.

- Le rayonnement haute fréquence (HF) peut provoquer des interférences avec les équipements de radio-navigation et de communication, les services de sécurité et les ordinateurs.
- Demander seulement à des personnes qualifiées familiarisées avec des équipements électroniques de faire fonctionner l'installation.
- L'utilisateur est tenu de faire corriger rapidement par un electricien qualifié les interférences résultant de l'installation.
- Si le FCC signale des interférences, arrêter immédiatement l'appareil.
- Effectuer régulièrement le contrôle et l'entretien de l'installation.
- Maintenir soigneusement fermés les portes et les panneaux des sources de haute fréquence, maintenir les éclateurs à une distance correcte

et utiliser une terre et un blindage pour réduire les interférences éventuelles.



**READ INSTRUCTIONS.
LIRE LES
INSTRUCTIONS.**

- Consult the Owner's Manual for welding safety precautions.
 - Use only genuine replacement parts
-
- Lire le manuel d'utilisation avant d'utiliser ou d'intervenir sur l'appareil.
 - Utiliser uniquement des pièces de rechange.

1-3. Safety Standards Normes de sécurité

Safety in Welding, Cutting, and Allied Processes, ANSI Standard Z49.1, from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ih.com).

Code for Safety in Welding and Cutting, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 178 Rexdale Boulevard, Rexdale, Ontario, Canada M9W 1R3 (phone: 800-463-6727 or in Toronto 416-747-4044, website: www.csa-international.org).

Safety in Welding, Cutting, and Allied Processes, ANSI Standard Z49.1, de Global Engineering Documents (téléphone : 1-877-413-5184, site Internet : www.global.ih.com).

Code for Safety in Welding and Cutting, CSA Standard W117.2, de Canadian Standards Association, Standards Sales, 178 Rexdale Boulevard, Rexdale, Ontario, Canada M9W 1R3 (téléphone : 800-463-6727 ou à Toronto 416-747-4044, site Internet : www.csa-international.org).

1-4. EMF Information EMF Information

Considerations About Welding And The Effects Of Low Frequency Electric And Magnetic Fields

Welding current, as it flows through welding cables, will cause electro- magnetic fields. There has been and still is some concern about such fields. However, after examining more than 500 studies spanning 17 years of research, a special blue ribbon committee of the National Research Council concluded that: "The body of evidence, in the committee's judgment, has not demonstrated that exposure to power- frequency electric and magnetic fields is a human-health hazard." However, studies are still going forth and evidence continues to be examined. Until the final conclusions of the research are reached, you may wish to minimize your exposure to electromagnetic fields when welding or cutting.

To reduce magnetic fields in the workplace, use the following procedures:

Considérations sur le soudage et les effets de basse fréquence et des champs magnétiques et électriques.

Le courant de soudage, pendant son passage dans les câbles de soudage, causera des champs électromagnétiques. Il y a eu et il y a encore un certain souci à propos de tels champs. Cependant, après avoir examiné plus de 500 études qui ont été faites pendant une période de recherche de 17 ans, un comité spécial ruban bleu du National Research Council a conclu : « L'accumulation de preuves, suivant le jugement du comité, n'a pas démontré que l'exposition aux champs magnétiques et champs électriques à haute fréquence représente un risque à la santé humaine ». Toutefois, des études sont toujours en cours et les preuves continuent à être examinées. En attendant que les conclusions finales de la recherche soient établies, il vous serait souhaitable de réduire votre exposition aux champs électromagnétiques pendant le soudage ou le coupage.

Pour réduire les champs magnétiques sur le poste de travail, appliquer les procédures suivantes :

1. Maintenir les câbles ensemble en les tordant ou en les enveloppant.

1. Keep cables close together by twisting or taping them.
2. Arrange cables to one side and away from the operator.
3. Do not coil or drape cables around your body.
4. Keep welding power source and cables as far away from operator as practical.
5. Connect work clamp to work piece as close to the weld as possible.

About Pacemakers:

Pacemaker wearers consult your doctor first. If cleared by your doctor, then following the above procedures is recommended

2. Disposer les câbles d'un côté et à distance de l'opérateur.
3. Ne pas courber pas et ne pas entourer pas les câbles autour de votre corps.
4. Garder le poste de soudage et les câbles le plus loin possible de vous.
5. Connecter la pince sur la pièce aussi près que possible de la soudure.

En ce qui concerne les stimulateurs cardiaques

Les porteurs de stimulateur cardiaque doivent consulter leur médecin avant de souder ou d'approcher des opérations de soudage. Si le médecin approuve, il est recommandé de suivre les procédures précédentes

SECTION 2 PACKING LIST

| MigSonic252S+SS20 package (Part No: 07000340) | | |
|---|----------------|-----------------|
| Description | Part no | Quantity |
| MigSonic252S Power source come with 10 ft. (3 M) Power cord and NEMA 6-50P 230V AC Plug | 07000342 | 1 |
| SS-20 wire feeder | 07000343 | 1 |
| 15 ft. (4.6M) WeldKing® NT2-15E industrial MIG torch w/ .035-.045 in (0.9-1.2 mm) liner. | 07000411 | 1 |
| Argon Regulator / Gauge/ Flow meter | 07000510 | 1 |
| Wire feeder Link cord assembly 10 ft (3M) | 07001830 | 1 |
| 300 Amp ground clamp with 10 ft (3 M) lead | 07000462 | 1 |
| Owner's Manual | 07000417 | 1 |

Table 2.1

SECTION 3 INSTALLATIONS

3-1. Welding power source and wire feeder specifications

| MigSonic252S power source | |
|---------------------------------------|-----------------------------|
| Welding Process | MIG/Flux cored wire Mig |
| Power supply | 200(208)V/230V |
| Phase | Single |
| Rated output current(A) | 250 |
| Input Amps @ rated output(A) | 50 |
| Rated input (KW) | 7.8 |
| Open circuit voltage(V) | 47 |
| Amperage range(A) | 50-300 |
| Welding voltage(V) | 13.5-26.5 |
| Duty cycle (%) @ 40°C | 60%@250A /26.5V |
| | 100%@200A /24V |
| Power factor | 0.72 |
| Protection class | IP23 |
| Insulation class | H |
| Operating temperature (°C) | -20 to +40 (-4°F to 104°F) |
| Storage temperature (°C) | -40 to +85 (-40°F to 185°F) |
| Machine dimension (HxWxD) (CM) | 47.5x24x43(18.7x9.4x17in) |
| Power source weight (KG) | 19.5(43lbs) |
| Packing dimension (HxWxD)(CM) | 63x38x50(25x15x20in) |

| | |
|--------------------|---------------|
| Packing weight(KG) | 23.5(51.8lbs) |
|--------------------|---------------|

Table 3.1



CAUTION!

WELDING LONGER THAN RATED DUTY CYCLE CAN DAMAGE GUN AND VOID WARRANTY.

| SS-20 wire feeder | |
|-------------------------------|--------------------------------|
| Type of Input power | 24 Volts DC Single Phase 60 Hz |
| Wire Feed Speed Range(M/MIN) | 1.5-18(59-709ipm) |
| Wire Diameter Range(MM) | 0.6-1.2(0.023-0.045in) |
| Protection class | IP23 |
| Max Spool Size Capacity(KG) | 27 (60lbs) coil |
| Insulation class | H |
| Operating temperature (°C) | -20 to +40 (-4°F to 104°F) |
| Storage temperature (°C) | -40 to +85 (-40°F to 185°F) |
| Dimension (HxWxD) (CM) | 60x29x46(24x11x18in) |
| weight (KG) | 8.2(18lbs) |
| Packing dimension (HxWxD)(CM) | 63x30x50(25x12x20in) |
| Packing weight(KG) | 8.5(18.7lbs) |

Table 3.2

3-2. MIG torch specifications

| | |
|--|---------------------------------|
| Model | NT2-15E (Part no.07000411) |
| Rated current(A) | 200A/CO ₂ , 150A/MIX |
| Rated Duty cycle (%) | 60 |
| Cool style | Air cooled |
| Wire diameter(mm) | 0.6-1.2(0.023-0.045in) |
| Cable length(M) | 4.6(15ft) |
| Connection | euro connection |
| Detailed gun specification please see separate torch manual. | |

Table 3.3

3-3. MIG welding connection diagram

MigSonic252S (208/230v input)




Figure 3.1

3-4. MIG/MAG Process/Polarity Table

| Process | Polarity | Cable Connections | |
|--|--------------------------|--|---------------------------------------|
| | | Cable To Gun | Cable To Work |
| GMAW – Solid wire with shielding gas | DCEP – Reverse polarity | Connect to positive(+) output terminal | Connect to negative(-)output terminal |
| FCAW – Self-shielding wire- no shielding gas | DCEN – Straight Polarity | Connect to negative(-) output terminal | Connect to positive(+)output terminal |

Table 3.4

3-5. General Installation procedure for MIG/MAG welding

3-5.1. Welding machine should be installed in a stable position and with good ventilation. Avoid direct sun outdoors. Avoid transport in invert or side position.

3-5.2. Be sure machine is well grounded.

3-5.3. Before starting a new machine or the machine idled for a period, check the insulation resistance of circuit which is connected to the network. The resistance must be higher than 2.5M Ω ; otherwise the machine must be dried.

3-5.4. Connect power source and wire feed with the link cord provided.

3-5.5. Connect torch, earth cable, wire, regulator, cylinder according to connection diagram. Note: Connection hardware must be tightened with proper tools. Do not just hands tighten hardware! A loose electrical connection will cause poor weld performance and excessive heating at the terminal block.

3-5.6. Make sure the spool gun selection switch locate inside drive motor compartment is set to "Mig gun". If this switch is set to "spool gun", the motor will not active when press the gun trigger.

3-5.7. Use $\Phi 8$ heat-resistant PVC hose connect the flow meter with the gas connection nipple at rear of the wire feeder.

3-5.8. Commission the machine after the machine is installed and tested:

- ★ Release the pressure roller in the wire feeder, push the torch switch, and adjust voltage switch from low to high, Open circuit voltage should rise.
- ★ Evenly adjust the current knob, the wire feed speed should increase evenly.

3-6. How to Install the wire spool

3-6.1. Install a spool of welding wire on the hub as follows: Press the upper side of spool case, and then pull the latch to open the cover. Unscrew spool nut from hub. Place wire spool on hub to rotate clockwise as wire is unwound; hub pin must engage hole in spool. Install spool nut.

3-6.2. The drive roll has two grooves; the small groove feeds 0.035 in. diameter wire, the large groove feeds 0.045 in. wire. The groove nearest the gear motor feeds the wire.

3-6.3. Release pressure drive roll assembly and lift upward. Check that proper wire diameter

groove is in the inner position. Feed the wire from the spool through the inlet guide, across the drive roll groove and into gun outlet guide. Lower pressure roll assembly and secure. Check that the gears mesh. Feed wire through to torch tip using the torch trigger.




Figure 3.2

3-7. How to Adjust wire feed pressure

Make sure that the wire moves smoothly through the wire guide. Then set the pressure of the wire feeder's pressure rollers. It is important that the pressure is not too high. Feed out the wire against an insulated object, e.g. a piece of wood. When you hold the gun approx. 5 mm from the object, the feed rollers should slip. When hold the gun approx. 50mm from the object, the wire should be fed out and bend. Now the pressure is properly set. See Figure 2.3.




Figure 3.3

3-8. How to Install spool gun(optional)

MigSonic252S use WeldKing® SpoolKing-24DL (Part no. 07NS1010) only. Use other model may not work properly.

- 3-8.1. Connect spool gun to the euro receptacle. Connect control cable to control receptacle located at front panel of SS20 wire feeder.
- 3-8.2. Toggle the spool gun selection switch to “spool gun” selection(see figure 3.4)
- 3-8.3. Install wire and commission according to spool gun instruction manual.




Figure 3.4

3-9. Electric service guide



CAUTION!

WARNING: THIS WELDING MACHINE MUST BE CONNECTED TO POWER SOURCE IN ACCORDANCE WITH APPLICABLE ELECTRICAL CODES

AVERTISSEMENT: LE RACCORDEMENT DE CETTE MACHINE DE SOUDAGE À L'ALIMENTATION DOIT ÊTRE CONFORME AUX CODES D'ÉLECTRICITÉ PERTINENTS

| | | |
|---|-----|-----|
| Input voltage(V) | 208 | 230 |
| Frequency(Hz) | 60 | 60 |
| Input Amperes at rated output(A) | 41 | 37 |
| Max recommended standard fuse Rating in Amp | | |
| Circuit breaker, time delay | 45 | 40 |
| Normal operation | 55 | 50 |

| | | |
|--|----|----|
| Min input conductor size in AWG | 8 | 8 |
| Min Grounding conductor Size in AWG | 10 | 10 |

Table 3.5

3-10. Extension Welding Cable Selection Chart



CAUTION! USE SHORTEST CABLE POSSIBLE

| Welding Amperes (A) | 100 | 150 | 200 |
|---|-------------------------|-------------------------|---------------------------|
| Maximum Cable Length allowed in Weld Circuit* (Ft) | Cable Size (AWG) | | |
| <=100 (30 m) | 4 (20mm ²) | 3 (30 mm ²) | 3 (30 mm ²) |
| 150 (45 m) | 4 (20 mm ²) | 2 (35 mm ²) | 1 (50 mm ²) |
| 200 (60 m) | 3 (30 mm ²) | 1 (50 mm ²) | 1/0 (60 mm ²) |

* The Cable Length in Weld Circuit is total of both weld cables and earth cables.

Table 3.6

3-11. 9-pin spool gun connection receptacle




Figure 3.5

| Socket pin | Function | Notes |
|------------|----------------------------------|-----------|
| 1 | Spool gun motor (-) | Green |
| 2 | Not used | |
| 3 | Not used | |
| 4 | Spool gun motor (+) | Red |
| 5 | Spool gun C.C.W potentiometer(3) | Brown red |
| 6 | Spool gun C.W potentiometer(1) | Blue |
| 7 | Spool gun wiper potentiometer(2) | Yellow |

| | | |
|---|----------|--|
| 8 | Not used | |
| 9 | Not used | |

Table 3.7

3-12. 7-pin link cord receptacle





Figure 3.6

| Socket pin | Function | Notes |
|------------|---|------------------------------------|
| 1 | Drive motor ground | Black |
| 2 | Solenoid valve ground | |
| 3 | Mig gun switch | |
| 4 | Voltage and wire feeding speed signal | 2.5V-24V DC reference to pin 1 |
| 5 | Common ground for voltage, wire feeding speed signal and gun switch | |
| 6 | Power supply to drive motor and solenoid valve | +24V DC reference to pin1 and pin2 |
| 7 | To purge switch | |


Table 3.8

SECTION 4 OPERATION

4-1. Power source panel layout and description



- | | |
|---|-------------------------------------|
| 1. Welding voltage meter (digital) | 4. Current display indication light |
| 2. Welding current/wire feeding speed meter (digital) | 5. Power indication light |
| 3. Wire feeding speed display indication light | 6. Protection indication light |
| | 7. Inductance adjustment knob |




- 8. Negative output (Earth clamp) connection
- 9. 9 pin control connection (to wire feeder)

- 10. Positive output (to wire feeder)
- 11. Power cord
- 12. Main switch


Figure 4.1

4-2. SS-2- wire feeder panel layout and description




- 1. Welding voltage adjustment knob
- 2. Welding current/wire feeding speed adjustment knob

- 3. Jog toggle switch
- 4. Purge toggle switch



- 5. Spool gun control connection
- 6. MIG torch euro connection
- 7. Gas inlet



- 8. 9 pin control connection (to power source)
- 9. Positive input (to power source)

Figure 4.2

4-3. Operation



USE SINGLE PHASE 208/230V POWER SUPPLY.

- 4-3.1. Switch on the power source.
- 4-3.2. Set the welding voltage knob to proper position and wire feed speed knob to a start value and refine during welding(referring to the voltage/wire feeding speed selection chart).
- 4-3.3. The display value of digital voltage meter will change when you turn the voltage knob to pre-set the welding voltage. And during welding, the voltage meter will reflect actual welding voltage. The display value of digital current meter will change when you turn the wire feed knob to pre-set the wire feed speed. The feeding speed light will illuminate indicating the meter is displaying wire feeding speed in inches per minute. The current light will illuminate and current meter will reflect actual welding current during welding.
- 4-3.4. Set the Arc control (inductance) knob to a start value according to the voltage/wire feeding speed selection chart you can adjust the knob during welding to obtain best result. Inductance is the rate of current response to a change in current. What this means is that when MIG welding with a short arc you can adjust how fast current is applied to the shorts. The less inductance you have the crisper the arc will appear and the wires will start easier. This will also make the bead taller and narrower. More inductance will make the arc appear "softer" with a flatter wider appearance and if too much is used, wires will stumble during starts. Typically when short arcing steel only a little inductance is used in order to get a crisp arc. Low thermal conductivity materials such as stainless need more inductance to get acceptable wetting when short arcing.
- 4-3.5. Push up "jog" switch to momentarily feed welding wire at speed set on Wire Speed control without energizing welding circuit or shielding gas valve. Push up "purge" switch to momentarily energize gas valve to purge air from gun or adjust gas regulator.
- 4-3.6. Turn on the gas valve, adjust gas volume to 3-5L/MIN. Press the torch switch check if wire feed and gas is normal, check if there is gas leaking.
- 4-3.7. Hold the torch and keep nozzle 8-12mm above the work piece, and tilt 10-20 ° to vertical direction. Aim wire to the welding seam.
- 4-3.8. Press torch switch, after arc is ignited, move the torch along seam evenly while keeping the stick-out. Fine tune the welding parameter to obtain exquisite welding seam. Release the torch switch to finish a welding cycle.
- 4-3.9. After finish operation, turn off the gas valve, loose the pressure handle at wire feeder, press torch switch to clear the residual gas in the regulator. At the end, turn off welding power source and wall switch.

4-4. Voltage/Wire speed selection chart

- : setting not recommended.

The setting in the following chart is just for start only and can be fine tune during welding.

6.5(Wire feed speed \varnothing)/4.5(Voltage "V")/7.5(Induction)

| MIG/MAG WELDING | | | | Polarity setting: DCRP(wire positive); Shield gas for steel: 80% Ar, 20%CO ₂ . Stainless steel and Al: 100% Ar. | | | | | | | | |
|------------------------|---------------|---------------|---------------|--|---------------|---------------|------------------------|---------------|---------------|---------------|---------------|--|
| Material | Steel | | | | | | Stainless steel | | | Aluminum | | |
| Wire type | Solid ER70S-6 | | | Flux core E71T-1 | | | ER308,ER308L,ER 308LSi | | | ER4043 | | |
| Wire size (in) (mm) | 0.023" 0.6 | 0.035" 0.9 | 0.045" 1.2 | 0.023" 0.6 | 0.035" 0.9 | 0.045" 1.2 | 0.023" 0.6 | 0.035" 0.9 | 0.045" 1.2 | 0.035" 0.9 | 0.045" 1.2 | |
| 1/2" (12.7mm) | - | - | 4.5/7.5/9 | - | - | - | - | - | - | - | - | |
| 3/8" (9.5mm) | - | 5.5/6.5/9 | 3.5/6.5/9 | - | - | 2.5/6/9 | - | 5.2/6.2/9 | 3.2/6.2/9 | 5.1/6.3/8 | 3.1/6.2/9 | |
| 1/4" (6.4mm) | - | 4.5/5.5/7.5 | 3.5/5.5/7.5 | - | 3.5/5.2/7 | 2.5/5.3/7.5 | - | 4.3/5.3/7.5 | 3/5.2/7.5 | 4.2/5.2/7.5 | 3.1/5.2/7 | |
| 3/16" (4.8mm) | 6.5/4.5/7.5 | 3.5/4.5/7.5 | 2.5/4.5/7.5 | 5/4/7.5 | 2.5/4/7 | 1.5/4.2/7.5 | 6/4.2/7 | 3.3/4.3/7 | 2.3/4.2/7 | 3.2/4.1/7.5 | 2.1/4.2/7 | |
| 1/8" (3.2mm) | 5.5/4.5/7.5 | 3.5/4.5/7.5 | 2.5/4.5/7.5 | 4.5/4/7.5 | 2.5/4/7 | 1.5/4.2/7.5 | 5/4.2/7 | 3.2/4.3/7 | 2.3/4.3/7 | 3/4.2/7. | 2.1/4.2/7 | |
| 14ga. (2.0mm) | 4.5/3.5/5 | 2.5/3.5/5 | 2.5/3.5/5 | 3.5/3.2/5 | 1.5/3/5 | 1.5/3.2/5 | 4/3/4 | 2.2/3.3/5 | 2.2/3.3/5 | 2.1/3.2/5 | 2.1/3.2/5 | |
| 16ga. (1.6mm) | 3.5/3.5/4 | 2.5/3.5/4 | 2.5/3.5/4 | 2.5/3.3/4 | 1.5/3/4 | - | 3.2/3.4/3 | 2.2/3.3/4 | 2.2/3.3/4 | - | - | |
| 18ga. (1.2mm) | 3.5/3.5/2.5 | 2.5/3.5/2.5 | 1.5/3.5/2.5 | - | - | - | 3.2/3.4/2.5 | 2.3/3.5/2.5 | 1.3/3/2 | - | - | |
| 20ga (0.9mm) | 2.5/2.5/1.5 | 1.5/2.5/1.5 | - | - | - | - | 2.3/2.5/1.5 | 1.3/2.5/1.5 | - | - | - | |
| 22ga. (0.8mm) | 2.5/2.5/1.5 | - | - | - | - | - | 2.2/2.5/1.5 | - | - | - | - | |

Table 4.1

SECTION 5 TROUBLE SHOOTING

5-1. General trouble shooting

| No. | Problem | | Cause | Solution |
|-----|---|---------------------------|----------------------------------|--|
| 1 | Power Indication lamp does not on after switch on the main switch | | Loose contact at input lead | Check contact situation |
| | | | Lamp malfunction, poor contact | Check contact situation. Replace lamp |
| | | | Main switch malfunction | Check switch, replace if necessary |
| 2 | Cooling fan stops to rotate after machine has worked a period | Power indication lamp on | Cooling fan circuit malfunction | Check fan circuit |
| | | | Cool fan failure | Check fan, replace if necessary |
| | | Power indication lamp off | See No. 1 | |
| 11 | Overheat light on | | Work excess the rate duty circle | Use under rate duty circle |
| | | | Input voltage is too high | Use under rate input voltage |
| 10 | Power supply switch jump | | Rectifier short circuit | Check and replace |
| | | | Main transformer short circuit | Check and replace |

| | | | |
|--|--|-----------------------------------|-------------------|
| | | Control transformer short circuit | Check and replace |
| | | Solenoid valve short circuit | Check and replace |
| | | Cooling fan short circuit | Check and replace |

Table 5.1

5-2. GMAW/FCAW welding trouble shooting

| No. | Problem | Cause | Solution |
|-----|--|-----------------------------|----------------------------------|
| 3 | No gas flow out after pushing the gun trigger | Gas pressure not enough | Check gas pressure |
| | | Poor gas hose connection | Check gas connection |
| | | Gun trigger failure | Check gun trigger |
| | | Solenoid valve failure | Check and replace Solenoid valve |
| | | Gas passage problem | Check and repair the gas passage |
| | | Torch gas hose problem | Check and repair torch cable |
| | | Control circuit failure | Replace circuit board |
| | | Control transformer failure | Replace transformer |
| 4 | Failure of arc to ignite or does not ignite properly | Fuse melt or poor contact | Check and repair |
| | | Main power switch failure | Check, repair, |

| | | | |
|---|--|--|--------------------------------------|
| | | | replace |
| | | Control circuit board failure | Check and repair the circuit board |
| | | Welding cable broken or poor contact | Check the connection |
| | | Gun trigger wire broken | Replace cable |
| | | Gun cable broken | Replace cable |
| | | Voltage adjustment knob failure or poor contact | Check, repair, replace |
| | | Control transformer failure | Check, repair, replace |
| | | Main transformer failure or poor contact | Check, repair, replace |
| 5 | Unstable arc | Gas hose not installed properly, gas mixed by air | Connect the gas hose firmly |
| | | Gas not pure | Changes gas |
| | | Wire liner or gun cable broken and leak cause insufficient gas volume. | Check, repair, replace |
| | | Wire pressure not setup properly | Adjust pressure properly |
| | | Wire feed speed not stable | See No.9 |
| | | Control circuit failure | Check, repair, replace circuit board |
| | | Gas heating failure | Check 20A Fuse, repair, replace |
| | | the work piece surface contaminated by oil | Clean the workpiece surface |
| | | Poor contact inside the gun | Check, repair, replace |
| 6 | Arc ignited but the wire does not melt | Rectifier tube failure | Check, replace |
| | | Output reactor failure | Check, replace |
| | | Output capacitor failure | Check, replace |
| 7 | Wire does not feed while the feed roller is rotating | Wire pressure not proper | Adjust pressure |
| | | Wire liner or contact tip jammed | Check, repair, replace |
| | | Used wrong groove at the feeding roller | Use the right groove |

| | | | |
|--------------------------|-------------------------------|--|---------------------------------|
| 8 | Cannot stop the gas | Solenoid valve contaminated | Check, repair, replace solenoid |
| | | Contactora failure | Check, replace the contactor |
| | | Control board failure | Check, repair, replace |
| 9 | Wire feeding not stable | Wire out of feeding roller groove | Put wire back |
| | | Wire feed pressure not set properly | Adjust pressure |
| | | Feeding roller deformed | Check and replace |
| | | Pressure roller deformed | Check and replace |
| | | Feeding motor failure | Check and replace |
| | | Current adjust potential meter failure | Check and replace |
| | | Circuit board plug socket not properly contacted | Check and repair or replace |
| | | Control circuit failure | Check and repair or replace |
| | | Welding hose deformed | Check and replace |
| Input voltage fluctuated | Use under rated input voltage | | |

Table 5.2

SECTION 6 MAINTENANCE

6-1. Maintenance

Periodic maintenance is necessary for keeping the machine work properly.



CAUTION!

DISCONNECT POWER INPUT AND SWITCH OFF THE MAIN POWER SWITCH BEFORE START OF MAINTENANCE.

| Regular Check and Inspection | |
|---|---|
| Power source | Wire feeder |
| <ul style="list-style-type: none"> • Check the function of all switches. • Check if the fan rotates properly and if there is air venting out from back of the machine. • Pay Attention to the abnormal vibration, noise, smell and gas leakage during operation. • Check if the welding cables are over heated. • Check if the cable connections are over heated? • Check if the cable is connected firmly and properly, if it is broken and cause bad insulation? • Check the cover grounded properly | <ul style="list-style-type: none"> • The pressure of the wire feeder's pressure rollers must be set properly. • If metal chips or dust pile up between the guide tube and feeding roller, clean and check if the feeding tube diameter is proper and is aligned with the center of the feeding roller. Also check if the feeding roller groove is same as the wire diameter and if there are objects inside groove. • Check pressure roller rolls smoothly and if it has been worn out. • Check if straightening roller it has been contaminated by oil, dust or metal chips. |

Table 6.1

| Regular Check and Inspection | |
|--|---|
| MIG torch | Cable |
| <ul style="list-style-type: none"> • Clean spatter inside the nozzle when continuously use the machine. • Check liner frequently, change if it has been contaminated by oil, deformed or worn out. • Check and change broken or deformed contact tip and nozzle to avoid damage to the torch and machine. | <ul style="list-style-type: none"> • Check if the welding cables are over heated. • Check if the cable connections are over heated? • Check if the cable is connected firmly and properly, if it is broken and cause bad insulation? |

Table 6.2

6 Month Routine Maintenance

6 Month Routine Maintenance

- Blow out with dry clean pressure air or vacuum inside machine, especially transformer coil and power component.
- Check the electric connection of input/output bar to avoid bad contact caused by loose or rusted screw.
- Check the contactors and relays in the machine or on the PCB work properly.
- Check the lubrication of the gear box in the feeder, replace or fill lubricates oil if necessary.
- Check and clean the oil or other contamination in the feeding roller and feeding tube. If the V grooves have worn out change feeding roller immediately to avoid slipping or unstable feeding

Table 6.3

6-2. Safety precaution

6-2.1. Welders must be equipped with welding mask, gloves and tie the sleeves and collar properly. Use Table 6.4 to choose proper glass shade, also can reference to ANSI Z49.1 listed in Safety Standards. There should be an arc shield around welding field to protect others from arc shock.

6-2.2. Do not weld near flammable, explosive materials or gases.

6-2.3. Gas cylinder must be located at a safe and steady place to avoid injury others.

6-2.4. Keep finger, hair and clothing away from the rotating fan.

6-2.5. The power source must be grounded when welding.

6-2.6. When yellow protection light is enlightened during welding, it is indicating that the welder is over current or over heat, and automatic protection will be triggered. Stop welding immediately and wait until welder cool down.

6-2.7. Welding machine should not work in a flammable and toxic environment, avoid moisture, rain, and do not directly expose to sun.

6-2.8. Do not switch off the welder during welding!

6-2.9. Periodically maintain the machine and clean the dust inside.

Lens Shade Selector Guide

| Operation /Process | Arc Current (Amperes) | Minimum Protective Shade | Suggested* Shade No. (Comfort) |
|--|-----------------------|--------------------------|--------------------------------|
| Gas metal arc welding (GMAW) and flux cored arc welding (FCAW) | Less than 60 | 7 | — |
| | 60–160 | 10 | 11 |
| | 160–250 | 10 | 12 |
| | 250–550 | 10 | 14 |

Table 6.4

SECTION 7 PARTS LIST

7-1. MigSonic252S Power Source

| Item | Order No. | Description | Note | Qty |
|------|----------------|----------------------------------|--|-----|
| 1 | 7.305.132 | Shunt | FL-1 75mv 300A short | 1 |
| 2 | 8.055RM.227-CA | Bottom plate | MIG 250F-1 c/w (S.004RM.227) | 1 |
| 3 | 8.065RM.078-B | Front output panel | MIG 250F-1 c/w (S.004RM.227-CA) | 1 |
| 4 | 8.069.004 | Front panel | Lincoln(arcweld 250i-ST DV) c/w(3.111.004) | 1 |
| 5 | 7.152.312-A | Quick connector/Female(zhengyun) | CX58 35-70MM | 2 |
| 6 | 7.132.055 | 7 pin receptacle | YD20K7Z(black) | 1 |
| 7 | 7.458.220-R | Knob | 2004-3(ID20)(KNOBS ERIES) (black/red with red needle white line) | 1 |
| 8 | 8.306RM.152 | Control panel | S.00RRM.227-CA control penal | 1 |
| 9 | W.496RM.135-G | Front panel | Base board:B.067RM.135-G | 1 |
| 10 | 8.301RM.229 | Cover | MIG-315F c/w 3.004RM.229 | 1 |
| 11 | 8.253.035 | Handle | lincoln (arcweld 250i-ST DV) c/w(3.111.004) | 1 |
| 12 | W.496RM.142-C | MIG250/315/350F power PCB | Base board(B.067RM.142-C) | 1 |
| 13 | 8.123RM.052 | Seal box | MIG-250 c/w 3.004RM.204 | 1 |
| 14 | 8.124RM.227-CA | Separating plate | MIG 315F | 1 |
| 15 | 8.123RM.904 | Supporting plate | Nylon c/w 3.004RM.203 3.004RM.204 | 1 |
| 16 | 8.422RM.054 | IGBT heat sink(1) | 168*61*44 (section bar 7.800.063) c/w 3.004RM.206 | 1 |

| | | | | |
|----|---------------|----------------------------|---|---|
| 17 | 7.425RM.001 | Single IGBT | FGH60N60SMD | 8 |
| 18 | 7.411.010 | Rectifier bridge | GBPC5010(plug type) | 2 |
| 19 | 7.231.061 | Thermostat (constant open) | TH-B2D75-K (c/w metal press plate) (SY) | 2 |
| 20 | 7.155.021 | Cable bracket | M2012B6-12 | 1 |
| 21 | 7.205.212 | Circuit breaker | DZ47-60-2P D63A/(60A) | 1 |
| 22 | 7.154.438-G | Power cord with plug | UL.SJ00W 12/3AWG (300V) 105/XN650P-A plug UL322682 Cable UL313867,3.3M | 1 |
| 23 | 8.123RM.064 | Circuit breaker bracket | galvanized sheet 1.0 c/w 3.004RM.206 | 1 |
| 24 | 8.068RM.227 | Real penal | MIG 250F-1 c/w (S.004RM.227) | 1 |
| 25 | 8.304RM.004 | Fan mesh | 92 fan mesh.123*100*58.5 with trench. c/w (3.004RM.206)(3.004RM.207) | 2 |
| 26 | 7.720.280-A | fan | 3610SB05WB60EOO cable length 300 (XinWei) | 2 |
| 27 | 5.496RM.091-B | Drive PCB for MIG250S | Base board (8.067RM.091-B) | 1 |
| 28 | 8.713RM.204 | Insulator | 0.3 polyester film 162.3*249 (MIG-250) | 1 |
| 29 | 5.496RM.059-A | MIG250 MUR PCB | Base board 8.067RM.059-A 1.6*170*121mm PCB | 4 |
| 30 | 8.423RM.007 | MUR heat sink(1) | 168*61*44 (7.800.064) | 6 |
| 31 | 8.422RM.055 | IGBT heat sink(2) | 64.5*61*44 (section bar 7.800.063) c/w 3.004RM.206 | 1 |
| 32 | 7.421.690 | Fast restore diode | STTH60P03SW | 8 |
| 33 | 8.423RM.008 | MUR heat sink(2) | 168*61*44 (7.800.064) | 1 |
| 34 | 8.422RM.056 | IGBT heat sink(3) | 76.5*61*44 (section bar 7.800.063) c/w 3.004RM.206 | 1 |

| | | | | |
|----|-------------|--|--|---|
| 35 | 6.185RM.206 | Main transformer | MIG-250S c/w 3.004RM.206 | 1 |
| 36 | 7.321.130 | inductor | 270mm length with cable 0.3sq mm 200round | 1 |
| 37 | 6.271RM.203 | inductance | MIG-250 c/w 3.004RM.023 3.004RM.204 | 1 |
| 38 | 7.731.031 | Control transformer | 220V input, 36V output(50W) | 1 |
| 39 | W.496RM.387 | Push-pull gun/spool gun selection PCB, 3 function,50V power supply | Base board B.067RM.387 | 1 |

Table 7.1




Figure 7.1

7-2. SS-20 Wire feeder

| Item | Order No. | Description | Note | Qty |
|------|----------------|---------------------------------------|--|-----|
| 1 | 8.051RM.901-CA | Right side plate | S.054RM.901-CA right side plate | 1 |
| 2 | 7.686.048 | Hinge | CL219-3 black matt(oubao) | 2 |
| 3 | 8.050RM.901-CA | Left side plate | S.054RM.901-CA left side plate | 1 |
| 4 | 7.686.300 | Latch | MS725-2 electric cabinet lock | 1 |
| 5 | 7.227RM.001-A | Toggle switch | R13 12A 125VAC 6A 250VAC 2*2 | 1 |
| 6 | W.496RM.364 | MIG250F-1 push/pull torch convert PCB | Base plate: B.067RM.364 | 1 |
| 7 | 8.123RM.220 | Solenoid valve attach plate | Box style wire feeder(c/w S.054RM.901-CA) | 1 |
| 8 | 7.253.014 | Solenoid valve | Model:YG2T-2,working pressure:0-0.8MPa,power supply:DC24V(gas inlet $\phi 8$) | 1 |
| 9 | 8.124RM.901-CA | Middle separating plate | S.054RM.901-CA middle separating plate | 1 |
| 10 | 8.069RM.906-D | Front panel | Box style wire feeder (S.054RM.901-CA) front panel | 1 |
| 11 | 7.456.905 | carbon potentiometer | RV24YN/20S B502 (TOCOS) | 2 |
| 12 | 8.123RM.221 | Control Panel | Box style wire feeder(c/wS.054RM.901-CA) | 1 |
| 13 | 7.458.360-R | Knob | 2004-1 (extra large $\phi 36*23$) (black/red with needle and white line) | 2 |
| 14 | 7.227.017 | Toggle switch | R9-32B/2A250V 1*2 | 2 |
| 15 | 7.132.009 | 9 pin receptacle | WEIPU SP2112/S9 SERIES CE | 1 |
| 16 | 7.667RM.203-A | Euro torch connection | Box style wire feeder S.054RM.901 | 1 |
| 17 | 7.510RM.001 | Insulation flange | MIG160R plastic ABS | 1 |

| | | | | |
|----|----------------|--------------------------------------|--|---|
| 18 | 8.177RM.203-A | Connection bar | Box style wire feeder S.054RM.901 | 1 |
| 19 | 8.178RM.203-A | Wire guide tube | Box style wire feeder S.054RM.901 | 1 |
| 20 | 8.462RM.030 | WEIPU receptacle locking nut | M21*1 S27 | 1 |
| 21 | 8.940.001 | Copper nut | M10×1 | 1 |
| 22 | 8.123RM.920-A | Euro connector attach plate | ABS with attach hole | 1 |
| 23 | 7.682.112 | caster | 2#Polyurethane, brown red | 2 |
| 24 | 8.123RM.176 | Caster attach plate | Box style wire feeder S.054RM.901 | 1 |
| 25 | 8.713RM.207 | Insulation film | Single drive motor insulation film 50*110, heat resistant polyester filmδ0.3 | 1 |
| 26 | 8.712.002 | Insulation sleeve | Φ22/Φ10.2 L=15mm | 2 |
| 27 | 7.662.801 | Insulation cap | JYM | 2 |
| 28 | 7.710.887 | Motor | 76YZ01 c/w 0.9-1.2 wire feeding roller, motor at left side | 1 |
| 29 | 7.132.507 | 7 pin receptacle | YD20K7Z(black) | 1 |
| 30 | 7.152.312-A | Quick connector female(zhengyuan) | CX58 35-70MM | 1 |
| 31 | 7.682.012 | Wheel | 2#Polyurethane, brown red | 2 |
| 32 | 8.123RM.177 | Wheel attach plate | Box style wire feeder S.054RM.901 | 1 |
| 33 | 8.055RM.901-CA | Bottom plate | S.054RM.901-CA bottom PCB | 1 |
| 34 | 7.803.002 | Europe spool box | Nanjing Dingrui 2 HOLE | 1 |
| 35 | 7.803.203 | Europe spool axle | Nanjing Dingrui 2 AXLE | 1 |
| 36 | 7.626.204 | Handel cover | Nanjing Dingrui 651 | 1 |

| | | | | |
|----|----------------|-------------------------|--------------------------------------|---|
| 37 | 8.303RM.901 | Middle separating plate | Box style wire feeder S.054RM.901 | 1 |
| 38 | 8.068RM.901-CA | Rear plate | S.054RM.901-CA REAR PLATE | 1 |
| 39 | 7.941.009 | Nut | GB/T6170 M12 | 1 |
| 40 | 8.462.641 | Gas inlet | GT-2000 | 1 |

Table 7.2




Figure 7.2

7-3. Wire driving system

Model 60/76ZY-01 with bracket.




Figure 7.3

| ITEM | DESCRIPTION | ORDER NO | QUANTIT | NOTE |
|------|--------------------------|----------|---------|-----------------------|
| 1 | Motor | 82010019 | 1 | 60/76ZY01 servo motor |
| 2 | Handle assembly | 0603033 | 1 | |
| 3 | Pressure roller assembly | 0603035 | 1 | |
| 4 | Inlet wire guide | 0603019 | 1 | |
| 5 | Hex nut | 1911019 | 1 | |
| 6 | Outlet wire guide | 0400093 | 1 | |
| 7 | Press knob | 0603016 | 1 | |

| | | | | |
|----|-------------------|---------|---|-----------------------------|
| 8 | Drive roller | 1507xxx | 1 | Default0.9/1.2(0.035/0.045) |
| 9 | connection sleeve | 0603015 | 1 | |
| 10 | Insulation sleeve | 0603022 | 2 | |
| 11 | Bracket | 0603031 | 1 | |
| 12 | Torch connection | 0603017 | 1 | |

Table 7.3

Drive roller selection

| ITEM | DESCRIPTION | ORDER NO | NOTE |
|------|--|----------|---------------------|
| 1 | V groove (0.9/1.2mm)(0.035/0.045)(default) | 07261030 | For solid wire |
| 2 | V groove (0.6/0.8mm)(0.023/0.030) | 07261031 | For solid wire |
| 3 | Knurled groove (0.9/1.2mm)(0.035/0.045) | 07261032 | For flux cored wire |
| 4 | U groove drive 0.9/1.2mm (0.035 /0.045) | 07261033 | For Aluminum wire |

Table 7.4

7-4. Spool holder module




Figure 7.4

| ITEM | DESCRIPTION | ORDER NO | QUANTITY |
|------|-------------------|----------|----------|
| 1 | Axle | 071709 | 1 |
| 2 | Axle seat inside | 071715 | 1 |
| 3 | Axle seat outside | 071710 | 1 |
| 4 | Damping washer | 071711 | 1 |
| 5 | Cap bracket | 071708 | 1 |
| 6 | Lock spring | 071707 | 1 |
| 7 | Lock nut | 071703 | 1 |
| 8 | Cap | 071706 | 1 |

Table 7.5

7-4. MIG torch

WeldKing® NT2-15E, Order No. 07000411




Figure 7.5

Nozzles

| ITEM | DESCRIPTION | ORDER NO. | |
|------|----------------------------|-----------|---|
| 1 | Nozzle Adjustable | 22-50* | A |
| 2 | Nozzle Adjustable | 22-62 | A |
| 3 | Nozzle Self Insulated | 22-50F | B |
| 4 | Nozzle Fixed Coarse Thread | 24CT60S | C |
| 5 | Nozzle Fixed Coarse Thread | 24CT62S | C |
| 6 | Nozzle Fixed Coarse Thread | 24CT75S | C |
| 7 | Nozzle Self Shielding | 23-50 | D |
| 8 | Nozzle Self Insulated | 23-62 | D |
| 9 | Nozzle Self Insulated | 23-75 | D |

| | | | |
|----|-------------------|-------|---|
| 10 | Nozzle Adjustable | 24A50 | E |
| 11 | Nozzle Adjustable | 24A62 | E |
| 12 | Nozzle Adjustable | 24A75 | E |

Table 7.6

Contact Tips

| ITEM | DESCRIPTION | ORDER NO. | |
|------|------------------------------|-----------|---|
| 1 | Contact Tip 0.023"/0.6mm Ecu | 14-23 | F |
| 2 | Contact Tip 0.030"/0.8mm Ecu | 14-30 | F |
| 3 | Contact Tip 0.035"/0.9mm Ecu | 14-35* | F |
| 4 | Contact Tip 0.040"/1.0mm Ecu | 14-40 | F |
| 5 | Contact Tip 0.045"/1.2mm Ecu | 14-45 | F |

Table 7.7

Liners

| ITEM | DESCRIPTION | ORDER NO. | |
|------|--|-------------|---|
| 1 | Steel Liner 0.030"-0.035"/0.8-0.9mm X15ft | 42-3035-15 | G |
| 1 | Steel Liner 0.040"-0.045"/1.0-1.2mm X15ft | 42-4045-15* | G |
| 2 | Teflon Liner 0.035"-0.045"/0.9-1.2mm X15ft | 42T-3545-15 | G |

Table 7.8

* Default

Component

| ITEM | DESCRIPTION | PART No. |
|------|--------------------------------|----------|
| 1 | Adjustable Nozzle Insulator | 32* |
| 2 | Nozzle Insulator Coarse thread | 34CT |
| 3 | Adjustable Nozzle Insulator | 34A |

| | | |
|----|----------------------------|----------|
| 4 | Gas Diffuser | 52 |
| 5 | Gas Diffuser | 52FN |
| 6 | Jacketed goose heck 45° | 62A45J |
| | Jacketed goose heck 60° | 62A60J* |
| | goose heck 45° | 62A45 |
| | goose heck 60° | 62A60 |
| 7 | Gas Nipple | TEF2212 |
| 8 | O-Ring 8x1.5 | Q508015S |
| 9 | Handle | TEH2101 |
| 10 | Hanger Hook | TEG2001 |
| 11 | Switch, OMRON | Q711 |
| 12 | Trigger | KJ3003 |
| 13 | Trigger Spring | Q60512 |
| 14 | Front Spring Cable Support | HS2101 |
| 15 | Cable assembly 15' | TEL2015 |
| 16 | Back Spring Cable Support | ES2201 |
| 17 | Gun Plug Housing | EH2201 |
| 18 | Screw M4X6 | EH2211 |
| 19 | Gun Plug Nut | EP3001 |
| 20 | Tweco Euro Gun Plug | TEU1001 |
| 21 | O-Ring 4x1 | Q504010 |
| 22 | O-Ring 4x1.8 | Q504018 |
| 23 | Nut M11X1 | TEU1011 |

Table 7.9

NOTES

WELDKING® MigSonic252S power source and SS20 wire feeder

SECTION 8 ELECTRIC DIAGRAM




Figure 8.1




Figure 8.2

SECTION 9 WARRANTY POLICY

Malo Welding Products Ltd., Warranty Policy

Effective August 1st, 2004, revision at April 1st, 2011

LIMITED WARRANTY - Subject to the terms and conditions below, Malo Welding Products Ltd.(WELDKING®) endeavors to provide high quality products and product support to its customers and therefore backs up all of its new products purchased from Malo Welding Products Ltd.(WELDKING®) or any authorized Malo Welding Products Ltd.(WELDKING®) distributor/service center after the effective date of this limited warranty and is free of defects in material and workmanship at the time it is shipped. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE FACE OF THE MALO WELDING PRODUCTS LTD.(WELDKING®) WARRANTY. MALO WELDING PRODUCTS LTD.(WELDKING®) DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, REGARDING THE PRODUCTS, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NONINFRINGEMENT. IN THE UNITED STATES, SOME STATES DO NOT ALLOW THE EXCLUSION OF THE IMPLIED WARRANTIES, SO THE ABOVE EXCLUSION MAY NOT APPLY TO YOU.

Malo Welding Products Ltd.(WELDKING®) shall honor warranty claims on warranted equipment listed below in the event of such a failure within the warranty time periods. All warranty time periods start on the date that the equipment was delivered to the original retail purchaser, or one year after the equipment is sent to a North American distributor.

(1) 3 Years - Parts and Labor

Power Sources

Wire Feeders

(2) 90 Days - Parts (No Labor)

Guns

Remote Controls

Accessory Kits

Replacement Parts (No labor)

Malo Welding Products Ltd.(WELDKING®)'s limited Warranty shall not apply to:

(1) Consumable components; such as contact tips, cutting nozzles, contactors, brushes, slip rings, relays or parts that fail due to normal wear.

(2) All limited warranties are void for, and Malo Welding Products Ltd.(WeldKing®) does not warrant in any way, any product that evidences misapplication, improper installation, abuse, lack of maintenance, negligence in use or care, abnormal use, alteration of design, use of incompatible or corrosive chemicals, and/or servicing, installation of parts, or repairs by anyone other than Malo Welding Products Ltd.(WELDKING®) or a Malo Welding Products Ltd.(WELDKING®) authorized distributor or service center. Malo Welding Products Ltd.(WELDKING®) may make changes in products it manufactures and markets at any time; these changes are made without obligation to change, retrofit, or upgrade any product previously sold or manufactured.

MALO WELDING PRODUCTS LTD.(WELDKING®) 'S PRODUCTS ARE FOR COMMERCIAL/INDUSTRIAL USE

AND PERSONS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING/PLASMA CUTTING EQUIPMENT.

In the event of a warranty claim covered by this warranty, the exclusive remedies shall be, at Malo Welding Products Ltd.(WELDKING®)'s option: (1) repair; or (2) replacement; or, where authorized in writing by Malo Welding Products Ltd.(WELDKING®), in appropriate cases, (3) the reasonable cost of repair or replacement at an authorized service station; or (4) payment of or credit for the purchase price (less reasonable depreciation based upon actual use) upon return of the goods at customer's risk and expense. No compensation or reimbursement for transportation costs of any kind will be allowed.

LIMITATION OF DAMAGES: THE REMEDY OF REPLACEMENT OR REPAIR OF ANY DEFECTIVE GOODS SHALL BE THE EXCLUSIVE REMEDY UNDER ANY WARRANTY MADE BY MALO WELDING PRODUCTS LTD.(WELDKING®), WHETHER EXPRESS OR IMPLIED. IN NO EVENT SHALL MALO WELDING PRODUCTS LTD.(WELDKING®) BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, PROPERTY DAMAGES, OR PERSONAL INJURIES.

ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY OR REPRESENTATION AS TO PERFORMANCE, AND ANY REMEDY FOR BREACH OF CONTRACT TORT OR ANY OTHER LEGAL THEORY WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, WITH RESPECT TO ANY AND ALL EQUIPMENT FURNISHED BY MALO WELDING PRODUCTS LTD.(WELDKING®), IS EXCLUDED AND DISCLAIMED BY MALO WELDING PRODUCTS LTD.(WELDKING®).

If any provision or portion of this limited warranty policy is found to be unenforceable, then the remaining provisions and portions shall remain valid and enforceable. If any provision or portion of this limited warranty policy is found to be limited by law, then that provision or portion shall be construed to make it effective within the bounds of law.

To obtain warranty service you must active your product(s)'s warranty online at weldking.com or mail the product registration card included in the package to Malo Welding Products Ltd.(WELDKING®) right after the purchase. When there is a warranty issue, return the defective welding machine or plasma cutting machine along with proof of purchase to any WeldKing® Authorized Warranty Depot. For the location of the nearest WeldKing® Authorized Warranty depot or for service information in the United States or Canada, please telephone toll free: 1-866-686-5088 or visit www.weldking.com (USA & Canada).available, but may vary from province to province.

SECTION 10 AUTHORIZED SERVICE CENTER

Please go to our website www.weldking.com to fill the warranty registration form. Malo Welding Products Ltd. will not distribute or disclose customer's private information to any third party and will not send promotion material to the customer.

Find your nearest warranty center at:

<http://www.weldking.com/servicelocations.aspx>

MALO WELDING PRODUCTS LTD.

271, Amber Street, Unit#10, Markham, ON L3R 3J7

Tel: 1 866 686 5088

Fax: 1 866 686 5090

www.weldking.com

Printed February 6, 2015